



## PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		SE00000521	SCREW PTB 3X8(ZK) 29S16308001	4	PC.
002		SE00000844	PCB A ASS'Y	1	PC.
003		SE00000521	SCREW PTB 3X8(ZK) 29S16308001	7	PC.
004	2	SE00001299	PCB C ASS'Y	1	PC.
005		SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2	PC.
006		SE00000848	PCB P ASS'Y (BAR ANT)	1	PC.
007		SE09090011	SCREW 1.7	5	PC.
008		SE00000849	POWER KEY HOLDER(BLK)	1	PC.
009		SE00000850	POWER KEY	1	PC.
010		SE09090011	SCREW 1.7	5	PC.
011		SE00000851	PRESET KEY HOLDER(BLK)	1	PC.
012		SE00000852	PRESET KEY	1	PC.
013		SE09064161	SCREW M4X16	4	PC.
014		SE00000853	FRONT CABINET ASS'Y	1	PC.
014	INC.		Item No. 7-12,17,18		
015		SE00000854	SCREW PTF 3X6(ZK)	2	PC.
016		SE00000521	SCREW PTB 3X8(ZK) 29S16308001	9	PC.
017		SE00000855	RUBBER KEY	1	PC.
018		SE00000856	FRONT PACKING	1	PC.
019		SE00000857	FRONT BUMPER	1	PC.
020		SE00000859	JACK RUBBER COVER	1	PC.
021		SE00000860	JACK COVER	1	PC.
022		SE00000754	EN/SW WASHER	1	PC.
023		SE00000755	EN/SW NUT	1	PC.
024		SE21B1110A	ROTARY KNOB RING	1	PC.
025		SE00000861	ROTARY KNOB(BLK)	1	PC.
026		SE00000862	FRONT BAR	2	PC.
027		SE00000709	SCREW PTHE 6X33(CR)	4	PC.
028		SE09176166	HEX SCREW M6X16	1	PC.
029		SE00000863	BATTERY BUMPER-L	1	PC.
030		SE09176166	HEX SCREW M6X16	1	PC.
031		SE00000864	BATTERY BUMPER-R	1	PC.
032		SE09176166	HEX SCREW M6X16	1	PC.
033		SE00000865	REAR BUMPER-L	1	PC.
034		SE09176166	HEX SCREW M6X16	1	PC.
035		SE00000866	REAR BUMPER-R	1	PC.
036		SE00000867	LOCKER COVER	1	PC.
037		SE00000868	PIN D2X84	1	PC.

Item No	Type	Part No	Description	Qty	Unit
038		SE00000536	LOCKER HINGE 3300B30000010	1	PC.
039		SE00000870	BATTERY COVER (BLUE)	1	PC.
039	INC.		Item No. 36-38,40,41		
040		SE00000539	PIN D2X77 2100B300200	1	PC.
041		SE00000872	XGT PLATE	1	PC.
042		SE00000521	SCREW PTB 3X8(ZK) 29S16308001	4	PC.
043		SE00000873	BATTERY COVER PACKING	1	PC.
044		SE0307PC5Z	BACK UP BATTERY COVER	1	PC.
045		SE021E9030	+/- BATTERY CONTACT ASS'Y	1	PC.
046		SE00000467	BATTERY CONTACT (-)2100PL00200	1	PC.
047		SE00000466	BATTERY CONTACT(+) 2100RA00700	1	PC.
048		SE9076146A	HEX SCREW M6X14	4	PC.
049		SE024J9070	PACKING	4	PC.
050		SE00000874	SPEAKER PANEL ASS'Y	1	PC.
051		SE09090023	SCREW M4X12	4	PC.
052		SE00000875	RIGHT SPEAKER ASS'Y	1	PC.
053		SE00000876	SPEAKER PACKING	1	PC.
054		SE00000877	BATTERY COVER FIXER PIN	1	PC.
055		SE00000404	SCREW PTHE 3X14(CR)	1	PC.
056		SE00000878	DC JACK COVER	1	PC.
057		SE00000176	SCREW PTHE6X20(CR)	1	PC.
058		SE00000715	SCREW PTHE 6X17(CR)	1	PC.
059		SE00000879	HANDLE L	1	PC.
060		SE00000881	HANDLE BAR	1	PC.
061		SE00000184	SPRING	2	PC.
062		SE09994007	STEEL BALL	2	PC.
063		SE09994007	STEEL BALL	2	PC.
064		SE00000184	SPRING	2	PC.
065		SE00000883	HANDLE R ANT(B)	1	PC.
066		SE00000176	SCREW PTHE6X20(CR)	1	PC.
067		SE00000716	SCREW PTHE 7X16(CR)	1	PC.
068		SE00000717	SCREW PTHE 10.8X4.5(CR)	1	PC.
069		SE00000886	REAR CABINET (BLUE) MR001G	1	PC.
069	INC.		Item No. 45-47,77		
070		SE00000445	SCREW PTB 3X45(NI)	2	PC.
071		SE00000888	HANDLE SUS-PLATE(R)	1	PC.
072		SE00000889	HANDLE SUS-PLATE(L)	1	PC.
073		SE00000890	DC JACK HOLDER	1	PC.
074		SE00000891	PCB F ASS'Y (DC JACK)	1	PC.

Item No	Type	Part No	Description	Qty	Unit
075		SE09090011	SCREW 1.7	2	PC.
076		SE00000892	SPEAKER HOLDER	1	PC.
077		SE00000587	LEAD WIRE W/CONNECTOR 170MM	1	PC.
078		SE00000892	SPEAKER HOLDER	1	PC.
079		SE00000876	SPEAKER PACKING	1	PC.
080		SE00000893	LEFT SPEAKER ASS'Y	1	PC.
081		SE09090023	SCREW M4X12	4	PC.
082		SE00000874	SPEAKER PANEL ASS'Y	1	PC.
083		SE024J9070	PACKING	4	PC.
084		SE9076146A	HEX SCREW M6X14	4	PC.
085		SE00000894	XGT TERMINAL(36V) ASS'Y	1	PC.
086		SE00000193	SCREW 3X10	5	PC.
087		SE00000895	CXT TERMINAL 10.8v-A-3PIN ASS'	1	PC.
088		SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2	PC.
089		SE00000896	LXT TERMINAL(18V) ASS'Y	1	PC.
090		SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2	PC.
091		SE00000897	PCB D+M ASS'Y (BATT._DET)	1	PC.
092		SE00000521	SCREW PTB 3X8(ZK) 29S16308001	4	PC.
093		SE00000898	W/TIES 150mm	1	PC.
094		SE00000195	W/TIES 100MM	1	PC.
095		SE00000899	REAR CABINET PACKING	1	PC.
A01		SE00000457	AC ADAPTER	1	PC.